



Support ring for FLOVAC® container (all sizes) with 25x5 slide	970010210	1
Support ring for FLOVAC® container (all sizes) with 30x5 slide	970010220	
Support ring for FLOVAC® container (all sizes) with 41x4 slide (also suitable for BAXTER wall slide)	970010214	
Support ring for FLOVAC® container with 45x5 slide (also suitable for ABBOT wall slide)	970010215	
Support ring for autoclavable jars (1000 and 2000 ml) with 25x5 slide	920200422	
ON-OFF tap for mounting on FLOVAC® container support ring	000010057	2
ON-OFF tap with control vacuum gauge for mounting on FLOVAC® container support ring	000010056	
Plastic wall slide 25x5	920200004	3
Plastic wall slide 30x5	920200029	
Plastic wall slide 45x5	920200477	
Metal clamp (chrome-plated) for 30x10 rail with slide 25x5	000230000	4
Plastic clamp (technopolymer) for 30x10 rail with slide 25x5	000230500	

Žiedas laikikliui ant bėgelio 25x5

970010210

Laikiklis ant bėgelio 25x5

920200004

FLOVAC® REUSABLE CONTAINERS

	ASPIRET ASKIR 20 ASKIR 30 ASKIR 230 12V BR ASKIR 36 BR ASKIR 118 118-WM	ASKIR C30 ASKIR C30 BR	HOSPIVAC 350 HOSPIVAC 400	For CENTRAL VACUUM PLANT
1000 ml Container	31843**			31840
2000 ml Container	31841	31841	31841	31841
3000 ml Container			31842	31842

** requires additional round spacer SP 0220 for ASKIR series only

