

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

<b>CHANNEL</b>	<b>CHANNEL MODE</b>	
	<b>STANDARD</b>	<b>VECTOR</b>
<b>1</b>	CYAN	CYAN
<b>2</b>	MAGENTA	MAGENTA
<b>3</b>	YELLOW	YELLOW
<b>4</b>	CTO	CTO
<b>5</b>	COLOR WHEEL	COLOR WHEEL
<b>6</b>	STOPPER / STROBE	STOPPER / STROBE
<b>7</b>	DIMMER	DIMMER
<b>8</b>	DIMMER FINE	DIMMER FINE
<b>9</b>	IRIS	IRIS
<b>10</b>	ANIMATION DISC or STATIC GOBO INSERTION	ANIMATION DISC or STATIC GOBO INSERTION
<b>11</b>	ANIMATION DISC ROTATION or STATIC GOBO CHANGE	ANIMATION DISC ROTATION or STATIC GOBO CHANGE
<b>12</b>	ROTATING GOBO CHANGE	ROTATING GOBO CHANGE
<b>13</b>	GOBO ROTATION	GOBO ROTATION
<b>14</b>	FINE GOBO ROTATION	FINE GOBO ROTATION
<b>15</b>	PRISM INSERTION	PRISM INSERTION
<b>16</b>	PRISM ROTATION	PRISM ROTATION
<b>17</b>	FROST 1	FROST 1
<b>18</b>	BLADE UP 1	BLADE UP 1
<b>19</b>	BLADE UP 2	BLADE UP 2
<b>20</b>	BLADE DOWN 1	BLADE DOWN 1

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

CHANNEL	CHANNEL MODE	
	STANDARD	VECTOR
21	BLADE DOWN 2	BLADE DOWN 2
22	BLADE RIGHT 1	BLADE RIGHT 1
23	BLADE RIGHT 2	BLADE RIGHT 2
24	BLADE LEFT 1	BLADE LEFT 1
25	BLADE LEFT 2	BLADE LEFT 2
26	FRAME ROTATION	FRAME ROTATION
27	FOCUS	FOCUS
28	FOCUS FINE	FOCUS FINE
29	ZOOM	ZOOM
30	AUTOFOCUS DISTANCE	AUTOFOCUS DISTANCE
31	AUTOFOCUS ADJUSTMENT	AUTOFOCUS ADJUSTMENT
32	PAN	PAN
33	PAN FINE	PAN FINE
34	TILT	TILT
35	TILT FINE	TILT FINE
36	FUNCTION	FUNCTION
37	RESET	RESET
38	DUMMY	DUMMY
39	FUNCTION 2	PAN/TILT TIME
40	FREQUENCY	COLOUR TIME
41	-	BEAM TIME
42	-	ROTATING GOBO TIME
43	-	FUNCTION 2
44	-	FREQUENCY

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function
Standard	Vector		
1	1		<b>CYAN</b>
		000 – 255	Linear Cyan movement
2	2		<b>MAGENTA</b>
		000 – 255	Linear Magenta movement
3	3		<b>YELLOW</b>
		000 – 255	Linear Yellow movement
4	4		<b>CTO</b>
		000 – 255	Linear CTO movement
5	5		<b>COLOR WHEEL</b>
		000	Empty position
		011	Empty + Dark Red
		021	Dark Red
		032	Dark Red + Green
		042	Green
		053	Green + CRI
		063	CRI
		074	CRI + Gold Amber
		084	Gold Amber
		095	Gold Amber + Navy Blue
		106	Navy Blue
		118	Navy Blue + Empty position
128 – 255	Continuous CCW Colour Wheel rotation at linearly variable speed from slow to fast		
6	6		<b>STROBE</b>
		000 – 003	Light OFF
		004 – 103	Strobe at linearly variable frequency from low (1 flash/sec) to high (25 flashes/sec)
		104 – 107	Light ON
		108 – 207	Pulsation at linearly variable speed from slow to fast
		208 – 212	Light ON
		213 – 225	Random Strobe at low frequency
		226 – 238	Random Strobe at medium frequency
		239 – 251	Random Strobe at high frequency
252 – 255	Light ON		
7	7		<b>DIMMER</b>
		000 – 255	Light output linearly increase from no-light to maximum brightness
8	8		<b>DIMMER FINE</b>
		000 – 255	Fine Dimmer positioning




# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function
Standard	Vector		
9	9		<b>IRIS</b>
		000 – 131	Iris linearly open from minimum to maximum aperture
		132 – 171	Iris pulsation from slow to fast speed
		172 – 211	Iris pulsation from slow to fast speed with fast opening
		212 – 251	Iris pulsation from slow to fast speed with fast closing
	252 – 255	Maximum aperture	
10	10		<b>ANIMATION DISC / STATIC GOBO INSERTION</b>
		000	Animation Disc / Static Gobo out
		001 – 255	Animation Disc / Static Gobo linear insertion
11 Standard	11 Standard		<b>ANIMATION DISC ROTATION</b> <i>If selected: Option → Animation Disk</i>
		000 – 124	Continuous animation disc CW rotation at linearly variable speed from fast (180 rpm) to slow (4.4 rph)
		125 – 130	Slow CW rotation
		131 – 255	Continuous animation disc CCW rotation at linearly variable speed from slow (4.4 rph) to fast (180 rpm)
11 Optional	11 Optional		<b>STATIC GOBO CHANGE</b> <i>If selected: Option → Fix Gobo Disk</i>
		000 – 125	Linear Gobo rotation
		126	Gobo 1
		129	Gobo 2
		132	Gobo 3
		135	Gobo 4
		138	Gobo 5
		141	Gobo 6
		144	Gobo 7
		146	Gobo 8
		147 – 188	Continuous rotation CCW at linearly variable speed from fast to slow
		189 – 191	Stop
		192 – 233	Continuous rotation CW at linearly variable speed from fast to slow
234 – 255	Gobo shakes at variable speed from slow to fast		

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function	
Standard	Vector			
12	12		<b>ROTATING GOBO CHANGE</b>	
		000 – 016	Empty position	
		017 – 032	Gobo 1 - GOD019/008 (Plumens)	
		033 – 048	Gobo 2 - GOD019/009 (Water Lines)	
		049 – 064	Gobo 3 - GOD019/010 (Multiple Cones)	
		065 – 081	Gobo 4 - GOD019/011 (Shattered)	
		082 – 097	Gobo 5 - GOD019/012 (Small Dots)	
		098 – 113	Gobo 6 - GOD019/014 (Broken Circle)	
		114 – 129	Gobo 7 - GOD019/013 (Half Circle)	
		130 – 147	Gobo 1 shakes at variable speed from slow to fast	
		148 – 165	Gobo 2 shakes at variable speed from slow to fast	
		166 – 183	Gobo 3 shakes at variable speed from slow to fast	
		184 – 201	Gobo 4 shakes at variable speed from slow to fast	
		202 – 219	Gobo 5 shakes at variable speed from slow to fast	
		220 – 237	Gobo 6 shakes at variable speed from slow to fast	
238 – 255	Gobo 7 shakes at variable speed from slow to fast			

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function
Standard	Vector		
13	13		<b>GOBO ROTATION</b>
		000 – 021	Gobo indexing: 0° to 90° range
		021 – 042	Gobo indexing: 90° to 180° range
		042 – 063	Gobo indexing: 180° to 270° range
		063 – 084	Gobo indexing: 270° to 360° range
		084 – 105	Gobo indexing: 360° to 450° range
		105 – 127	Gobo indexing: 450° to 540° range
		128 – 190	Continuous CW gobo rotation at linearly variable speed from fast (180rpm) to slow (2.2rph)
		191 – 192	Stop rotation
193 – 255	Continuous CCW gobo rotation at linearly variable speed from slow (2.2rph) to fast (180rpm)		
14	14		<b>FINE GOBO ROTATION</b>
		000 – 255	Fine CCW Gobo Indexing
15	15		<b>PRISM INSERTION</b>
		000 – 127	Prism out
		128 – 255	4 facet Prism into the light beam
16	16		<b>PRISM ROTATION</b>
		000 – 021	Prism indexing: 0° to 90° range
		021 – 042	Prism indexing: 90° to 180° range
		042 – 063	Prism indexing: 180° to 270° range
		063 – 084	Prism indexing: 270° to 360° range
		084 – 105	Prism indexing: 360° to 450° range
		105 – 127	Prism indexing: 450° to 540° range
		128 – 190	Continuous CCW prism rotation at linearly variable speed from fast (80rpm) to slow (3rph)
		191 – 192	Stop rotation
193 – 255	Continuous CW prism rotation at linearly variable speed from slow (3rph) to fast (80rpm)		
17	17		<b>FROST</b>
		000 – 255	Frost moves linearly into the light beam Frost blades move from no-diffusion to maximum diffusion
18	18		<b>BLADE UP 1</b>
		000 – 255	Blade moves linearly into the light beam
19	19		<b>BLADE UP 2</b>
		000 – 255	Blade moves linearly into the light beam
20	20		<b>BLADE DOWN 1</b>
		000 – 255	Blade moves linearly into the light beam
21	21		<b>BLADE DOWN 2</b>
		000 – 255	Blade moves linearly into the light beam

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function
Standard	Vector		
22	22		<b>BLADE RIGHT 1</b>
		000 – 255	Blade moves linearly into the light beam
23	23		<b>BLADE RIGHT 2</b>
		000 – 255	Blade moves linearly into the light beam
24	24		<b>BLADE LEFT 1</b>
		000 – 255	Blade moves linearly into the light beam
25	25		<b>BLADE LEFT 2</b>
		000 – 255	Blade moves linearly into the light beam
26	26		<b>FRAME ROTATION</b>
		000 – 255	Frame CCW linearly rotate
27	27		<b>FOCUS</b>
		000 – 255	Focus moves linearly from far to near position
28	28		<b>FOCUS FINE</b>
		000 – 255	Fine Focus positioning
29	29		<b>ZOOM</b>
		000 – 255	Zoom linearly moves from narrow to wide beam
30	30		<b>AUTOFOCUS DISTANCE</b>
		000 – 006	Autofocus disabled
		007 – 255	Autofocus from 4mt. (bit 7) to 100mt. (bit 255)
31	31		<b>AUTOFOCUS ADJUSTMENT</b>
		000 – 127	Focus Fine
		128	Stop
		129 – 255	Focus Fine
32	32		<b>PAN</b>
		000 – 255	Pan CCW movement/positioning from 0° to 540° (default setting)
33	33		<b>PAN FINE</b>
		000 – 255	Fine Pan positioning
34	34		<b>TILT</b>
		000 – 255	Tilt CCW movement/positioning from 0° to 268° (default setting)
35	35		<b>TILT FINE</b>
		000 – 255	Fine Tilt positioning

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function
Standard	Vector		
36	36		<b>FUNCTION</b>
		000 – 011	Unused range
		012 – 024	Fast Pan/Tilt speed
		025 – 037	Normal Pan/Tilt speed
		038 – 050	Conventional Dimmer curve
		051 – 062	Standard Dimmer curve
		063 – 075	CMY shortcut ON
		076 – 088	CMY shortcut OFF
		089 – 101	Slow blades speed
		102 – 113	Fast blades speed
		114 – 126	Fast rotating Gobos change
		127 – 139	Normal rotating Gobos change
		140 – 152	Quadratic Dimmer curve
		153 – 164	400W Led Power
		165 – 177	500W Led Power
		178 – 215	Free
		216 – 228	Linear Dimmer Curve
		229 – 231	Option – Display On/Off reversal
232 – 233	300W Led Power		
234 – 255	Free		
		The functions are activated/selected passing through the unused levels range and staying in the necessary range for 5 seconds	
37	37		<b>RESET</b>
		000 – 025	Unused range
		026 – 076	Effects Reset Effects Reset sequence is activated passing through the unused levels range and staying in this range for 5 seconds
		077 – 127	Pan / Tilt Reset Pan/Tilt Reset sequence passing through the unused levels range and staying in this range for 5 seconds.
128 – 255	Complete Reset All-effects Reset sequence passing through the unused levels range and staying in this range for 5 seconds.		
38	38		<b>DUMMY</b>
		000 – 255	-

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

Channel Mode		DMX Value	Function			
Standard	Vector					
39	43		<b>FUNCTION 2</b>			
		000 – 011	Unused range			
		012	Base Frequency= 4700 Hz			
		013	Base Frequency= 6000 Hz			
		014	Base Frequency= 7300 Hz			
		015	Base Frequency= 8600 Hz			
		016	Base Frequency= 10000 Hz			
		017	Base Frequency= 12000 Hz			
		018	Base Frequency= 15000 Hz			
		019	Base Frequency= 17578 Hz			
		020	Base Frequency= 20000 Hz			
		021	Base Frequency= 22000 Hz			
			The functions are activated/selected passing through the unused levels range and staying in the necessary range for 5 seconds			
40	44	000 – 255	<b>FREQUENCY</b>			
			<b>Base Frequency (see Function 2)</b>	<b>Min Freq. @ 0 bit</b>	<b>Frequency @ 128 bit</b>	<b>Max Freq. @ 255 bit</b>
			4700 Hz	4060 Hz	4700 Hz	5335 Hz
			6000 Hz	5360 Hz	6000 Hz	6635 Hz
			7300 Hz	6660 Hz	7300 Hz	7935 Hz
			8600 Hz	7960 Hz	8600 Hz	9235 Hz
			10000 Hz	9360 Hz	10000 Hz	10635 Hz
			12000 Hz	10720 Hz	12000 Hz	13270 Hz
			15000 Hz	13336 Hz	15000 Hz	16651 Hz
			17578 Hz	16682 Hz	17578 Hz	18467 Hz
			20000 Hz	18720 Hz	20000 Hz	21270 Hz
			22000 Hz	21360 Hz	22000 Hz	22635 Hz
		-	39	000 – 255	<b>PAN-TILT TIME</b> Pan - Fine Pan - Tilt - Fine Tilt	
-	40	000 – 255	<b>COLOUR TIME</b> Cyan - Magenta – Yellow – CTO – Color wheel			
-	41	000 – 255	<b>BEAM TIME</b> Dimmer - Frost - Prism – Focus – Zoom			
-	42	000 – 255	<b>ROTATING GOBO TIME</b> Rotating Gobo			



# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

DMX Channels  
10/2020

### IMPORTANT

*To prevent accidental breakage of the effects, which could collide with each others during transport, before switching the projector OFF check that all the projector Channels have been excluded (DMX level = 0 bit.).*

*To preserve the LED engine, it is suggested to set the Dimmer @ 0bit a few minutes before turning off the fixture.*

*To ensure reliable operation of the effects, it is suggested to keep the Light of the fixture On, for few minutes before moving the effects. Claypaky use a high-performance lubricant (Barrierta L55/0) that is designed to work within the high temperature environment in Claypaky's modern moving light fixtures. In cold environments, it may take several minutes for the lubricant to reach optimum fluidity and all functions to reach optimum performance.*

# Axcor Profile 600 TEATRO

## Axcor Profile 600 HC TEATRO

### VECTOR MODE TIME TABLE

BIT	Seconds
0	Full
1	0.2
2	0.4
3	0.6
4	0.8
5	1
6	1.2
7	1.4
8	1.6
9	1.8
10	2
11	2.2
12	2.4
13	2.6
14	2.8
15	3
16	3.2
17	3.4
18	3.6
19	3.8
20	4
21	4.2
22	4.4
23	4.6
24	4.8
25	5
26	5.2
27	5.4
28	5.6
29	5.8
30	6
31	6.2
32	6.4
33	6.6
34	6.8
35	7
36	7.2
37	7.4
38	7.6
39	7.8
40	8
41	8.2
42	8.4

BIT	Seconds
43	8.6
44	8.8
45	9
46	9.2
47	9.4
48	9.6
49	9.8
50	10
51	10.2
52	10.4
53	10.6
54	11
55	12
56	13
57	14
58	15
59	16
60	17
61	18
62	19
63	20
64	21
65	22
66	23
67	24
68	25
69	26
70	27
71	28
72	29
73	30
74	31
75	32
76	33
77	34
78	35
79	36
80	37
81	38
82	39
83	40
84	41
85	42

BIT	Seconds
86	24
87	25
88	26
89	27
90	28
91	29
92	30
93	31
94	32
95	33
96	34
97	35
98	36
99	37
100	38
101	39
102	40
103	41
104	42
105	43
106	44
107	45
108	46
109	47
110	48
111	49
112	50
113	51
114	52
115	53
116	54
117	55
118	56
119	57
120	58
121	59
122	60
123	61
124	62
125	63
126	64
127	65
128	66

BIT	Seconds
129	41
130	42
131	43
132	44
133	45
134	46
135	47
136	48
137	49
138	50
139	51
140	52
141	53
142	54
143	55
144	56
145	57
146	58
147	59
148	60
149	61
150	62
151	63
152	64
153	65
154	66
155	67
156	68
157	69
158	70
159	71
160	72
161	73
162	74
163	75
164	76
165	77
166	78
167	79
168	80
169	81
170	82
171	83

BIT	Seconds
172	58
173	59
174	60
175	61
176	62
177	63
178	64
179	65
180	66
181	67
182	68
183	69
184	70
185	71
186	72
187	73
188	74
189	75
190	76
191	77
192	78
193	79
194	80
195	81
196	82
197	83
198	84
199	85
200	86
201	87
202	88
203	89
204	90
205	91
206	92
207	93
208	94
209	95
210	96
211	97
212	98
213	99
214	100
215	101

BIT	Seconds
216	170
217	180
218	190
219	200
220	210
221	220
222	230
223	240
224	250
225	260
226	270
227	280
228	290
229	300
230	310
231	320
232	330
233	340
234	350
235	360
236	370
237	380
238	390
239	400
240	410
241	420
242	430
243	440
244	450
245	460
246	470
247	480
248	490
249	500
250	510
251	520
252	530
253	540
254	550
255	Follow cue Data