

Updating the Fixture Library 7.4.

This guide will cover updating the fixture library in Onyx 4.32

Getting Started

To get started, you will need the following:

1. A computer connected to the internet
2. USB Thumb Drive (If loading onto a Console)
3. An Onyx Console or PC running Onyx version 4.6.xxxx or later.


Downloading the Fixture Library

1. Download the fixture library onto your computer from the [Obsidian Downloads](#) website.
 - The fixture library is updated daily with new fixture profiles.
2. Once the download is complete, copy the file to the USB thumb drive if loading onto a console.

Importing the Fixture Library


1. If loading onto a console, plug the USB thumb drive into a blue USB port on the rear of the console.
2. Open the Onyx Menu by pressing or selecting the Onyx logo in the upper left corner of the screen.

3. Select Manage



4. From the Menu on the left select Tools

5. Select Update next to "Update Fixture Library."



6. If on a console, select the Fixture Library File from the USB thumb drive and press **open** , or if on a PC, choose Library Fixture File from the downloads folder.

7. Onyx will now update Fixture Library.