


## Emergency halt for safety



### Precautions:

The default configuration for overseas is an emergency stop button with a twist-to-restore mechanism. This type of button does not support self-restoration after an emergency stop; it can only be released by twisting the button.




Automatic operation

Automatic charging

The machine is in the process of automatic cleaning operation or automatically returning to the charging dock.

1



3



During the process of automatic cleaning operations or automatically returning to the charging dock, if an emergency situation arises, press the emergency stop button to put the machine into an emergency stop state

2

When the machine is in an emergency stop state, operate the screen as follows:

1. Tap 'Delay Recovery' to hide the emergency stop interface; the machine will automatically release the emergency stop state after the countdown ends.
2. Tap 'Abandon Reset' to forgo the automatic recovery from the emergency stop; it can only be restored later by pressing the emergency stop knob again.
3. Tap 'Maintenance Mode' to enter the maintenance mode, where you can follow the guidance to maintain and clean the accessories.
4. If no operation is performed, the machine will automatically release the emergency stop state after the countdown ends.