



## Thermo Scientific Paraffin

### Thermo Scientific Paraffin Selection Matrix

Description	Additives	Melting Point	Type	Use
Paraffin Type 1	None	55 - 57 °C	Flake	Infiltration
Shandon Histoplast	None	56 - 57 °C	Flake	Infiltration/Embedding
Paraffin Type 3	Plastic Polymers	55 - 57 °C	Flake	Infiltration/Embedding
Histoplast PE	Plastic Polymers	56 - 57 °C	Pellet	Infiltration/Embedding
Signature Series™ Type L	Plastic Polymers	55 - 57 °C	Flake	Infiltration/Embedding
Paraffin Type 6	Microcrystalline Wax	55 - 57 °C	Flake	Infiltration/Embedding
Histoplast IM	Plastic Polymers & DMSO	56 - 57 °C	Pellet	Infiltration/Embedding
Precision Cut	Plastic Polymers	56 - 57 °C	Pellet	Infiltration/Embedding
Signature Series Type H	Plastic Polymers	55 - 57 °C	Flake	Infiltration/Embedding
Histoplast LP	Plastic Polymers & Microcrystalline Wax	50 - 54 °C	Pellet	Infiltration/Embedding
Paraffin Type 9	Plastic Polymers	55 - 57 °C	Flake	Infiltration/Embedding